# CABINET PARTS

REFRIGERATOR

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CABINET PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | | Literature Parts |
| | 2318493 | Use & Care Guide |
| | 2223996 | Installation Instructions |
| | 2322230 | Service & Wiring Sheet |
| | 2220407 | Modular Icemaker Service Sheet |
| | 2322226 | Energy Guide |
| | 2220407 | Modular Icemaker Service Sheet |
| 2 | | Front Roller Asm |
| | 2306950 | Left Side |
| | 2306951 | Right Side |
| 3 | 2223263 | Strap, Roller |
| 4 | 2306949 | Roller, Rear (2) |
| 5 | 2223388 | Clip, Retainer (4) |
| 6 | 2155013 | Clip, Grille |
| 7 | 489478 | Screw |
| 8 | 2223545 | Shim |
| 9 | | Hinge Top, RC |
| | 2307008B | Black |
| 10 | 3400113 | Screw |
| 11 | 3400243 | Screw |
| 12 | 2307179 | Hinge Assembly, Bottom−RC (Includes # 34) |
| 13 | | Filler, Wrapper |
| | 2223893B | Black |
| 14 | | Grille |
| | 2322234B | Black |
| 15 | 3400108 | Screw |
| 16 | | Hinge, Top FC |
| | 2307007B | Black |
| 17 | 489464 | Screw |
| 18 | 2304888 | Drain Fitting |
| 19 | 2254566 | Tube, Extension |
| 21 | 2223409 | Cover, Unit |
| 22 | 2223387 | Pin, Roller (4) |
| 23 | 549193 | Clamp, Service Cord |
| 24 | 489084 | Screw |
| 25 | 2307152 | Hinge Assembly, Bottom−FC (Includes # 29) |
| 26 | | Button, Water Filter |
| | 2260503B | Black |
| 27 | 2260526 | Housing, Water Filter |
| 28 | 4396841 | Water Filter |
| 29 | 2307051 | Door Closer, FC |
| 30 | | Cap, Water Filter |
| | 2260518B | Black |
| 31 | | Cabinet (Not A Serviceable Part) |
| 32 | 489483 | Screw |
| 34 | 2307049 | Door Closer−RC |
| 35 | 3400858 | Screw |
| 36 | 2304709 | Tube, Filter Outlet |
| 37 | 2319868 | Tube, Filter Inlet |

# REFRIGERATOR LINER PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | | Liner (Not A Serviceable Part) |
| 2 | 2223524 | Escutcheon, Meat Pan Control |
| 3 | 2223339 | Slide Meat Pan Control |
| 6 | 1118894 | Switch, Rocker Arm |
| 7 | 2188820 | Thermistor |
| 9 | 2319866 | Ladder, Shelf (2) |
| 10 | 2317740 | Housing, Door Control |
| 11 | 489084 | Screw |
| 12 | 3400893 | Screw |
| 14 | 2171846 | Release Valve |
| 17 | 2317105 | Cover, Thermistor |
| 18 | 489478 | Screw |
| 19 | 2304597 | Gasket, Air Baffle |
| 20 | 2223403 | Cover, Air Baffle |
| 21 | 2224076 | Air Diffuser Assembly |
| 22 | 2220377 | Air Baffle |
| 23 | 2162085 | Socket |
| 24 | 2223876 | Reservoir |
| 25 | 2205813 | Strap |
| 26 | 2255743 | Light Bulb |
| 27 | 2223663 | Light Lens |
| 28 | 488280 | Screw |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR SHELF PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 2223288 | Pan Assembly (Includes #31) |
| 2 | 2223309 | Button, Humidity |
| 3 | 2223308 | Slide, Humidity |
| 5 | 2203027 | Cover, Meat Pan (Includes Items 13, 14, 15 & 20) |
| 6 | 2223261 | Snack Pan |
| 9 | 2223592 | Cover, Crisper (Includes 2 & 3) |
| 10 | 2223591 | Glass, Cover |
| 13 | 2174478 | Eyelet, Roller |
| 14 | 2188212 | Roller |
| 15 | 489211 | Screw |
| 16 | 2223235 | Crisper Pan |
| 17 | 2223526 | Meat Pan (Includes 13, 14, 19 & 22) |
| 18 | 2224059 | Shelf and Frame Assembly (3) |
| 19 | 489261 | Screw |
| 20 | 2223487 | Deflector |
| 22 | 2203029 | Handle |
| 25 | 2196485 | Stud Assembly |
| 27 | 3400894 | Screw |
| 28 | 2196483 | Stud Assembly |
| 29 | 8281158 | Screw |
| 31 | 2223320 | Slide, Pan |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER LINER PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# FREEZER LINER PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | | Liner (Not A Seviceable Part) |
| 3 | 3400893 | Screw (4) |
| 6 | W10130088 | Basket, Deep (2) |
| 7 | 8534064 | Screw (8) |
| 9 | 2223500 | Shelf Assembly, Cantilever (2) |
| 11 | 2223782 | Front, Basket |
| 12 | 2224053 | Front−Basket (2) |
| 13 | | Shelf Track |
| | 2223787 | Right Side |
| | 2223788 | Left Side |
| 14 | 2254615 | Shelf, Fixed |
| 15 | W10130090 | Basket, Lower |
| 17 | 842534 | Clip, Air Duct (2) |
| 18 | | Glide Assembly, Basket (2) |
| | 2224137 | Right Side |
| | 2224138 | Left Side |
| 19 | 2223991 | Cover, Emitter |
| 22 | 2198635 | Spring |
| 23 | 2198634 | Pin |
| 24 | 2198665 | Tube, P.C. Board |
| 25 | 1115373 | Switch, Rocker Arm |
| 26 | 2220398 | P.C. Board Emitter |
| 27 | 2223321 | Cover, Ice Maker |
| 28 | | Slide, Ice Maker Mounting |
| | 2212321 | Right Side |
| | 2306900 | Left Side |
| 29 | 489478 | Screw |
| 30 | 489214 | Screw |
| 32 | 2162085 | Light Socket |
| 33 | 2255743 | Light Bulb |
| 34 | 8281185 | Screw |
| 35 | 2198633 | Flipper |
| 36 | 2255558 | Cover, Receiver |
| 37 | 2255562 | Slide, Ice Maker Shut Off |
| 38 | 2255114 | P.C. Board, Receiver |
| 39 | 2198643 | Lens |
| 40 | 2198589 | Light Shield |
| 41 | 2212340 | Light Lens |
| 42 | 2198641 | Bracket, Ice Maker Cover |
| 43 | 2155597 | Socket, Light |
| 45 | | Ladder |
| | 2320024 | Left Side |
| | 2320025 | Right Side |
| 46 | 2303378 | Shield, Wiring |

# MOTOR AND ICE CONTAINER PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**



# MOTOR AND ICE CONTAINER PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 2223317 | Ice Bin |
| 2 | 2317254 | Crusher Bin |
| 3 | 2317240 | Auger |
| 4 | 2258220 | Washer |
| 5 | 1119007 | Spacer, Flat (4) |
| 6 | 2317248 | Cover, Crusher |
| 7 | 2257022 | Blade, Rotary |
| 8 | 1119005 | Spacer, Step (2) |
| 9 | 2257020 | Blade, Fixed |
| 10 | 2257023 | Blade, Rotary |
| 11 | 2317239 | Block, Blade |
| 12 | 489229 | Roll Pin |
| 13 | 2257024 | Blade, Rotary |
| 14 | 489235 | Washer, Plain |
| 15 | 2198661 | Washer, Coupling |
| 16 | 2188918 | Coupling |
| 17 | 8281164 | Screw |
| 18 | 3400065 | Screw |
| 20 | 2317262 | Latch, Bin |
| 21 | 2198608 | Spring, Latch |
| 23 | 8281163 | Screw |
| 24 | 2188919 | Holder |
| 25 | 2317243 | Wiper |
| 26 | 2198628 | Seal |
| 27 | 2317250 | Divider−Chamber |
| 28 | 2188916 | Drive Shaft |
| 29 | 2256154 | Enclosure, Motor |
| 30 | 2315547 | Dispenser, Motor |
| 31 | 2212305 | Cover |
| 32 | 2315559 | Sleeve, Coupling |
| 33 | 2187725 | Wire Harness, IDI Motor |
| 100 | 2317266 | Ice Container (Complete) |

# REFRIGERATOR DOOR PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# REFRIGERATOR DOOR PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | | Refrigerator Door (Includes #7) |
| | 2307199S | Stainless Steel |
| | 2327924LG | Stainless VCM |
| 2 | 2203087K | Trim, Shelf |
| 3 | 2255421 | Dairy Door |
| 4 | 2223463K | Door Bin |
| 6 | 2219698 | Stud, Handle |
| 7 | | Door Gasket, Magnetic |
| | 2223911 | Black |
| 8 | | Handle (Includes #9) |
| | 2254600S | Stainless |
| 9 | W10010140 | Screw |
| 10 | 2223879 | Dairy Compartment |
| 11 | 488208 | Screw |
| 12 | 2307048 | Door Closer, Upper Cam |
| 13 | 2308091 | Thimble, Top |
| 14 | 489420 | Screw |
| 15 | | Bracket, Door Stop |
| | 2306940B | Black |
| 16 | 2304952K | Door Bin (2) |
| 17 | 3400012 | Screw |
| 18 | 2224173 | Door Bin, Shallow |
| 20 | 2156006K | Plug, Trim |
| 21 | 2255121 | Nameplate |

# FREEZER DOOR PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**



# FREEZER DOOR PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13 (Stainless Steel) (Stainless VCM)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | | Freezer Door (Includes #8 And Dispenser Front Parts) |
| | 2327677SB | Stainless Steel |
| | 2327677LG | Stainless VCM |
| 2 | | Handle (Includes #6) |
| | 2254600S | Stainless |
| 3 | 2219698 | Stud, Handle |
| 4 | 488208 | Screw |
| 5 | 3400012 | Screw |
| 6 | W10010140 | Screw |
| 7 | 2171157K | Shelf Bin (3) |
| 8 | | Door Gasket, Magnetic |
| | 2223912 | Black |
| 10 | 2219982 | Trim, Door Shelf |
| 11 | 2308091 | Thimble, Top |
| 14 | 2307050 | Door Closer, Upper Cam |
| 16 | 489420 | Screw |
| 17 | | Bracket, Door Stop |
| | 2306940B | Black |

# DISPENSER FRONT PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# DISPENSER FRONT PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13 (Stainless Steel) (Stainless VCM)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | | Housing, Dispenser (Not Serviced) |
| 2 | 3196537 | Screw |
| 3 | 2194719 | Retainer, Levers |
| 4 | 2304772 | Spring, Torsion |
| 5 | 2196195 | Pin |
| 6 | 2180353 | Door, Ice |
| 7 | 2304355 | Door Mechanism Assembly |
| 8 | 2205686 | Mechanism Delay |
| 9 | | Grille, Overflow |
| | 2206670B | Black |
| 10 | 2209718 | Water Fitting Assembly (Includes Water Tube) |
| 11 | | Lever, Ice Dispenser |
| | 2255431B | Black |
| 12 | 2180224 | Guide, Ice |
| 13 | 2305571 | Gasket |
| 15 | 2323009 | Bracket, Control |
| 17 | | Lever, Water Dispenser |
| | 2255432B | Black |
| 19 | | Overlay, Front Cover (Not Available, Order #23) |
| 20 | | LED Display (Not Available, Order #23) |
| 21 | | Front Cover, Housing (Not Available, Order #23) |
| 22 | 489000 | Screw |
| 23 | | Front Cover Assembly (Includes Items 13, 19, 20 & 21) |
| | 2318490B | Black |
| 24 | 2304673 | Bracket, Dispenser |
| 25 | 2195051 | Strain Relief |
| 26 | 3400065 | Screw |
| 27 | 2252127 | Sleeve, Mechanism |

# AIR FLOW PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 2182120 | Fan Scroll |
| 2 | 2155590 | Retainer, Fan Motor |
| 3 | 2223298 | Air Scoop |
| 4 | 2223303 | Air Duct, Upper |
| 5 | 2223771 | Air Duct Freezer |
| 6 | 2319914 | Bi−Metal, Defrost |
| 7 | 2315548 | Fan Motor |
| 8 | 2169142 | Fan Blade |
| 9 | 2304241 | Gasket, Evaporator Cover (2) |
| 10 | 2176759 | Fan Grommet (2) |
| 12 | 2310339 | Harness, Fan Evaporator (Includes #6) |
| 13 | 2155789 | Gasket, Fan Scroll |
| 16 | 2203876 | Gasket |
| 17 | 2223413 | Cover, Evaporator (Includes #9) |
| 18 | 8281159 | Screw (6) |
| 21 | 489478 | Screw |
| 22 | 2223395 | Support, R.S |
| 23 | 2203596 | Support, L.S |

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# CONTROL PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**




| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 2319752 | Control Box (Includes #6) |
| 2 | 2223877 | Latch |
| 3 | 2306952 | Trim, Control Box |
| 4 | 2223512 | Spring, Torsion |
| 5 | 2223882 | Heat Shield Asm |
| 6 | 2307037 | Control Board Asm |
| 7 | 2223506 | Light Lens, Control Box |
| 8 | 2223857 | Light Socket (2) |
| 9 | 2326255 | Light Bulb (2) |

# UNIT PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# UNIT PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 777070 | Screw |
| 2 | 2225834 | Fan, Blade |
| 3 | 2223315 | Condenser Assembly |
| 4 | 8281197 | Screw |
| 6 | 2223703 | Housing, Control Board |
| 7 | 2223351 | Tube Suction |
| 8 | 2161302 | Sleeve |
| 9 | 3400524 | Screw (6) |
| 10 | 2301979 | Plate, Mounting |
| 11 | 8281196 | Screw |
| 12 | 2319835 | Grommet−Cond. (4) |
| 13 | 489373 | Screw (4) |
| 14 | 2185788 | Clamp, Cable |
| 15 | 488649 | Screw |
| 16 | 2319793 | Start Device−Combo Relay & Overload |
| 17 | 2169373 | Capacitor |
| 18 | 2223353 | Tube, Condenser to Heat Loop |
| 19 | 2323180 | Electronic Control |
| 20 | 2306932 | Baseplate |
| 21 | 489478 | Screw |
| 22 | 2188823 | Evaporator |
| 23 | 2161324 | Clamp |
| 24 | 2188729 | Fan, Motor |
| 25 | 2223398 | Tray, Evaporator |
| 26 | 2224022 | Heat Shield |
| 27 | 2317845 | Drier |
| 28 | 2318414 | Compressor (Includes Item # 39) |
| 29 | 2223800 | Spacer (5) |
| 30 | 2255199 | Retaining Clip |
| 31 | 2187850 | Harness, Main Control |
| 32 | 2224024 | Fan, Motor Bracket |
| 33 | 2210737 | Heater, Defrost |
| 34 | 2304287 | Clip |
| 35 | 2169104 | Insulation, Sound |
| 38 | 2223352 | Tube, Discharge |
| 39 | | Grommet (4) |
| | 1100826 | Production |
| | 4387558 | Service |
| 40 | 2223394 | Extension, Air Baffle |
| 41 | 2155547 | Clip, Heat Shield |
| 42 | 2187737 | Unit Harness |
| 43 | 2209709 | Connector, Water Tube |

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|

Following Parts Not Illustrated and Optional Parts Not Included

| | |
|---|---|
| 978025 | Valve, Access (1/4") |
| 978026 | Valve, Access (5/16") |
| 978027 | Valve, Access (3/8") |
| 978028 | Valve, Access (1/2") |
| 978029 | Valve, Access (5/8") |
| 978030 | Valve, Access (3/4") |
| 876764 | Valve, Access (3/16") |

## REFRIGERANT CHARGE

6.00 oz.
(R−134A)

# ICEMAKER PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

# ICEMAKER PARTS

**For Models: EC3JHAXRS13, EC3JHAXRL13 (Stainless Steel) (Stainless VCM)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|
| 1 | 489084 | Screw |
| 2 | 2256096 | Fitting, Water Tube |
| 3 | 628379 | Clip, Fuse |
| 4 | 489478 | Screw |
| 5 | 2315533 | Water Valve Asm |
| 6 | 2208136 | Tube Clip |
| 7 | 2174358 | Cover |
| 8 | 488649 | Screw |
| 9 | 628228 | Mold & Heater Assembly (Also Order 542638 |
| 10 | 628356 | Cup, Water Fill |
| 11 | 627843 | Ejector |
| 12 | 2198598 | Ice Striper |
| 13 | 2194712 | Support |
| 14 | 2315522 | Retainer, Thermostat |
| 15 | 627985 | Thermostat (Also Order 542369 Cement Alumilastic) |
| 16 | 8533917 | Screw |
| 17 | 489276 | Screw |
| 18 | 2187467 | Harness, Wiring |
| 19 | 2303583 | Bracket, Icemaker Mounting |
| 20 | 626691 | Module Assembly (Includes Items 21 & 22) |
| 21 | 626684 | Motor |
| 22 | 489136 | Screw |
| 100 | 2198597 | Icemaker Assembly |

# OPTIONAL PARTS (NOT INCLUDED)

**For Models: EC3JHAXRS13, EC3JHAXRL13**
**(Stainless Steel) (Stainless VCM)**

| Illus. No. | Part No. | DESCRIPTION |
|---|---|---|

**PAINT, PRESSURIZED SPRAY (12 oz.)**

| | |
|---|---|
| *350942 | Primer, White |
| *350939 | Black |
| *8171357 | Graphite |

**PAINT, TOUCH−UP (1/2oz.)**

| | |
|---|---|
| 72032 | Black |
| 80051 | Graphite |

*__Important:__ The spray paint is not to be used where the paint may make contact with the door gaskets.

**PAINT, BULK (1 qt.)**

| | |
|---|---|
| 799340 | Black |
| 8171358 | Graphite |

**Miscellaneous**

| | |
|---|---|
| 212643 | Sealer, Gum (4 Feet) |
| 479502 | Tape, Vinyl (3/4 x 108") |
| 505587 | Sealer, Mastic (1 Qt.) |
| 503695 | Cork, Sealer (1/4 Pound) |
| 542638 | Grease, Silicone (1/2 Oz.) |
| 542639 | Cement, Alumilastic (1−1/4 Oz.) |
| 799833 | Kit, Evaporator Repair (Aluminum Epoxy) |
| 833938 | Kit, Terminal Connector |

**TORX SCREW WRENCH**

| | |
|---|---|
| 1117510 | Torx Key |